



ScourStop® INSTALLATION GUIDELINES



ScourStop may be used in many applications: culvert outlets, curb outfalls, spillways, overflow structures, stream banks, slopes, etc. The details in this example are for typical culvert outlet protection. Project engineer shall determine the limits of soil cover and ScourStop.

- Downstream:** Continue soil cover beyond outlet apron area to properly protect downstream channel and prevent head-cutting.
- Width:** Install soil cover wider than proposed ScourStop protection (recommend soil cover full width of channel – across bottom and up both slopes).



- Electric Hammer:**
- **Rotary hammer or demolition hammer** – the greater the impact energy (ft/lbs) and the heavier the hammer, the greater the driving force to install bullet anchors into soil (e.g., Makita HM1214C, Hilti or other).
 - Use **hammer-only mode**, no rotation.
 - Use 3/4" Ground Rod Driver, which fits onto ScourStop HD Driver.
 - Recommend two ScourStop drivers per electric hammer to achieve maximum efficiency.

- Maintenance:**
- No maintenance is required for a ScourStop solution.
 - Mowing over a vegetated ScourStop solution is allowed – minimum height of 4" recommended.
 - Mowing is not recommended where soft, saturated soils exist.
 - ScourStop surface may be slippery when wet – **use caution**.
 - New construction: soil may consolidate, so lock washers may need to be re-tightened after settling.



PERFORMANCE • AESTHETICS
NPDES-COMPLIANT • COST-EFFECTIVE






ScourStop® INSTALLATION GUIDELINES





Site Preparation:

- 1 Finish grading to ensure positive drainage and eliminate ponding.
- 2 Create defined drainage channel to carry stormwater at outlet and downstream.
- 3 Compact soil in all areas of fill to create firm seed bed.
- 4 Install subsurface drainage tile if constant water is expected.
- 5 Grade a smooth transition from outlet to discharge area (allow for soil cover thickness and ScourStop thickness).
- 6 Max. 2" drop from culvert outlet/curb opening to top of ScourStop mats (no waterfall impact).






ScourStop Transition Mat Installation:

- 1 After proper grading and installation of selected soil cover, place ScourStop mats beginning at culvert outlet/curb opening, or at toe of slope, stream bank, or spillway.
- 2 Place ScourStop mat(s) adjacent to culvert/curb and adjacent to other ScourStop mats to avoid gaps.
- 3 Do not overlap adjacent mats unless necessary to conform to channel geometry.
- 4 If desired, ScourStop mats may be cut with circular saw or hand saw.




Soil Cover:





- 1 ScourStop must be placed over soil cover (sod, TRM, or geotextile) – not over bare ground, therefore, install soil cover first.
- 2 Channel flow data must be evaluated to determine proper soil cover.
- 3 Install sod; water thoroughly after completing installation.
- 4 Or install turf reinforcement mat (TRM), after seed and fertilizer, then water thoroughly after completing installation.
- 5 Non-vegetated: install geotextile (minimum 6 oz. non-woven geotextile fabric).



ScourStop Bullet Anchors:



- 1 Use ScourStop bullet anchors (minimum of 8 anchors per mat) to secure mats on top of soil cover and tightly to the soil surface.
- 2 Insert bullet anchor strap into lock washer (3"-4").
- 3 Insert the machined end of the driver into the bullet anchor.
- 4 Drive anchor through a 2" hole in mat (per recommended anchor pattern), stopping before lock washer is at least 1" above mat.
- 5 Twist and pull the driver out of the soil. Wipe driver tip with rag or glove to remove soil.
- 6 Grasp end of strap with one hand and push down on lock washer with the other until lock washer is flush with mat.
- 7 Place foot on top of lock washer, then give a firm tug on the strap (quick tug, like setting a fish hook) to set the pivoting bullet anchor.
- 8 Use additional anchors if necessary to secure mats tightly to soil surface.





Bowman
Construction
Supply Inc.



Quick
Supply Co.



Cascade
GEOSYNTHETICS

LOCATIONS & CONTACT INFO

ASP ENTERPRISES

aspent.com
salesasp@aspent.com

BOWMAN CONSTRUCTION SUPPLY

bowmanconstructionsupply.com
salesbcs@bowmanconstructionsupply.com

QUICK SUPPLY CO.

quicksupplyco.com
salesquick@quicksupplyco.com

CASCADE GEOSYNTHETICS

cascadegeos.com
salescascade@cascadegeos.com

St. Louis, MO 636.343.4357
Omaha, NE 402.861.8579
Kansas City, MO 816.554.1191
Wichita, KS 316.393.1554

Denver, CO 303.696.8960
Colorado Springs, CO 719.257.7840
Loveland, CO 970.535.0863

Des Moines, IA
515.289.1271

Portland, OR
971.339.1020

SOLUTIONS WE SUPPLY

GEOSYNTHETICS

Filter Fabrics

Stabilization Fabrics

Geogrids

- Road Grids
- Wall Grids
- Slope Stabilization

Specialty Fabrics

Composite Geomembranes

- GCLs, PVC, HDPE, LLDPE, EPDM, Granular Bentonite

SEDIMENT CONTROL

Inlet Protection

- Grated Inlet, Curb Inlet, Area Inlet Protection

Ditch Checks

- Triangle Silt Dike
- GeoRidge

Perimeter Protection

- High and Low-Porosity Silt Fence, Straw Wattles, Silt Socks
- Safety Fence

Flocculants & Water Treatment

- Polymer-Based & Natural Flocculants

Sediment Basin Skimmers

Dewatering Bags

Trackout Control

- FODS
- Rumble Grates

Turbidity Curtains

EROSION CONTROL

Basic Hydraulically Applied Mulches

- Wood
- Paper
- Blends
- Straw

High-Performance Hydraulically

Applied Products

- BFM
- FGM
- Additives & Tackifiers

Temporary Erosion Control Blankets

- Coir & Jute Mat/Nettings
- Short-Term ECBs
- Extended-Term ECBs

Permanent Erosion Control Blankets

- Turf Reinforcement Mats
- HP-TRMs
- Anchor Reinforced Vegetation System

Structural BMPs

- Transition Mats
- Geoweb Cellular Confinement
- Composite Vegetated Armor System
- Flex MSE Vegetated Wall System
- Articulated Concrete Block
- Gabions
- Grout-Filled Geotextile Mats

Vegetation Establishment

- Native Seed & Turf Seed
- Fertilizers
- Organic Soil Additives
- Stratavault Soil Cells

STORMWATER MANAGEMENT

Water Quality

- Inlet Filter Boxes
- Pre-Treatment Chamber
- Nutrient Separating Baffle Boxes
- High-Flow Biofiltration Media
- Hydrodynamic Separators
- Stratavault

Water Quantity

- Modular Underground Storage Systems
- Chamber Detention Systems

Drainage

- HDPE Swale Liner
- Pipe & Fittings
- Drainage Composites
- Strip Drain

Inlet Structures

- PVC
- Drain Basins, In-Line Drains
- Landscape

Permeable Pavers

- Permeable Articulating Concrete Block
- Grass Pavers
- Gravel Pavers
- Concrete Pavers

SPECIALTY

Natural & Synthetic Coir Fiber Logs

Vegetated Reinforced Soil Slopes

Soil Anchors

Root Barrier System

AquaBlok

Muscle Wall

We are full line distributors of construction materials for all project types. Contact us for assistance with a project. From specification and development to installation and completion, we're here to help with all of your site solution needs.

GEOSYNTHETICS | EROSION CONTROL | STORMWATER MANAGEMENT
SEDIMENT CONTROL | REVEGETATION & SOIL AMENDMENTS